



**Primary funding is provided by**

**The SPE Foundation through member donations  
and a contribution from Offshore Europe**

The Society is grateful to those companies that allow their  
professionals to serve as lecturers

**Additional support provided by AIME**



Society of Petroleum Engineers  
Distinguished Lecturer Program  
[www.spe.org/dl](http://www.spe.org/dl)

# Shale Development – Does Cheap Energy Really Mean Flaming Tap Water?

Dr. William W. Fleckenstein, PE (CA #1666)

Colorado School of Mines



Society of Petroleum Engineers  
Distinguished Lecturer Program  
[www.spe.org/dl](http://www.spe.org/dl)

# Presentation Outline



- Introduction
- Why is US shale development important?
- Aquifer protection
- Wattenberg study
- Summary
- Questions and answers

# Longmont Panel Discussion Sept. 19, 2012

Dr. Frackenstein



# Introduction

- Shale development:
  - Controversial
  - Leakage estimates disputed
- This presentation provides a fact based estimate of leakage



Images from "Gasland The Definitive Documentary on Fracking"


# Why is US Shale Development Important?



Weekly U.S. Field Production of Crude Oil


[↓ DOWNLOAD](#)

Thousand Barrels per Day




Source: U.S. Energy Information Administration

# Shale Plays Around the World




# Historical Well Construction

- The first recorded salt well in China
  - 2,250 years ago
- Persian oil development
  - 8 centuries ago
- Baku hand-dug holes to 35 meters
  - 4 centuries ago




# More “Modern” Drillers

- To access the subsurface you need a hole.
- To drill a hole, typically an aquifer is encountered.
- Early drillers recognized the need to case aquifers but:
  - How deep?
  - Good cement job?
  - Legacy wells?




# Aquifer Protection




- Aquifer protection:
  - Drill through the aquifer to an impermeable formation
  - Run surface casing and cement

Simple?




# Denver Basin Aquifers



Cross section of the Denver Basin aquifer system (USGS 1995)


# Does Methane Exist in Fresh Water Aquifers?



Biogenic gas, having a microbial origin, is naturally occurring in aquifers (think swamp gas).

Thermogenic gas is associated with deeper oil and gas maturation – may be from oil and gas development or the source may be natural seepage, as shown here.

# Aquifer Methane




Distribution and Origin of Groundwater Methane in the Wattenberg Oil and Gas Field of Northern Colorado - Li and Carlson 2014

# Aquifer Protection

Wellbores should have at least three barriers in place


1. Cemented surface casing
2. Cemented prod. casing
3. Annular hydrostatic head



# Contamination Probability Hypothesis

Multiplication rule for independent events can be used to estimate aquifer contamination.

$$P = \prod_{i=1}^N P(A_i)$$



What if a barrier failure probability is 5% or 1/20?


# Hypothesis: 5% Individual Barrier Failure

During production:  
three independent failures

1. Cemented surface casing
2. Cemented production casing
3. Annular hydrostatic head

During fracturing: two more:

4. Frac string pressure monitoring
5. Annular pressure monitoring



R.A. Freeze and J.A. Cherry. 1979. *Groundwater*. Prentice Hall. 604pgs.


# Contamination Probability Hypothesis - Production

Probability of hydrocarbon migration:

$$P = \prod_{i=1}^N P(A_i)$$

$$P = 0.05^3$$

1 per 8,000 wells.




# Contamination Probability Hypothesis - Fracturing

- Probability of frac fluid migration:

$$P = \prod_{i=1}^N P(A_i)$$


$$P = 0.05^{15}$$

- 1 per 3,200,000 wells.




# Aquifer Protection Case Study

- The Wattenberg Field near Denver, CO.
- Data from 17,948 oil wells (1970 – 2013).
- Wells were classified by construction types.
- **Possible barrier failures:**
  - Remedial cementing below the surface casing
  - Possible presence of Sustained Annular Pressure
- **Catastrophic barrier failures:**
  - Thermogenic gas detected in offset water wells combined with barrier failure in an adjacent well.



Bonanza Creek


# Wattenberg Pressure Profile






# Surface Casing Setting Depths

Historical surface casing setting depths pre-cement remediation.




1970's shallow surface casing depths were designed the purpose of well control during drilling operations and not for aquifer isolation




# Cementing Practices

**Historical production top of cement (TOC) depths post-cement remediation.**





The Niobrara and Codell formations, at an average depth of 6,950 – 7,400 ft TVD, were thought to be unproductive until their “discovery” in the early 1980’s.




# Well Design Risks

CATEGORY	DESCRIPTION
1	SHALLOW SURFACE CASING + TOP OF PRODUCTION CASING CEMENT BELOW OVER PRESSURED HYDROCARBON RESERVOIR
2	SHALLOW SURFACE CASING + TOP OF PRODUCTION CASING CEMENT BELOW UNDER PRESSURED HYDROCARBON RESERVOIR
3	SHALLOW SURFACE CASING + TOP OF PRODUCTION CASING CEMENT ABOVE TOP OF GAS
4	SHALLOW SURFACE CASING + TOP OF PRODUCTION CASING CEMENT ABOVE SURFACE CASING SHOE
5	DEEP SURFACE CASING + TOP OF PRODUCTION CASING CEMENT BELOW UNDER PRESSURED HYDROCARBON RESERVOIR
6	DEEP SURFACE CASING + TOP OF PRODUCTION CASING CEMENT ABOVE TOP OF GAS
7	DEEP SURFACE CASING + TOP OF PRODUCTION CASING CEMENT ABOVE SURFACE CASING SHOE


# Wellbore Design Impacts



# Well Designs in Use



# Well Barrier Possible Failures



# Potential and Catastrophic Barrier Failures



VERTICAL AND DEVIATED WELLS										
	ORIGINAL WELL COUNT	POTENTIAL BARRIER FAILURES	POTENTIAL BARRIER FAILURE %	CATASTROPHIC BARRIER FAILURES	CATASTROPHIC BARRIER FAILURE %	AVG COMPLETION DATE	P&A WELL COUNT	CURRENT WELL COUNT	ORIGINAL AVG SURFACE CASING DEPTH (FT)	ORIGINAL AVG TOP OF PRODUCTION CEMENT (FT)
CATEGORY 1	166	100	60.24%	3	1.81%	1979	57	15	253	7,334
CATEGORY 2	621	219	35.27%	5	0.81%	1983	138	301	306	6,566
CATEGORY 3	46	16	34.78%	1	2.17%	1987	14	31	321	4,008
CATEGORY 4	7	0	0.00%	0	0.00%	1982	1	15	222	125
CATEGORY 5	8,789	77	0.88%	1	0.01%	1995	782	6,140	559	6,111
CATEGORY 6	5,433	6	0.11%	0	0.00%	2007	105	7,181	712	2,816
CATEGORY 7	1,766	0	0.00%	0	0.00%	2009	8	2,040	719	534
<b>TOTAL</b>	<b>16,828</b>	<b>418</b>	<b>2.48%</b>	<b>10</b>	<b>0.06%</b>		<b>1,105</b>	<b>15,723</b>		
D&A	147									

SPE-181696 • An Assessment of the Probability... • Fleckenstein

973 horizontal wells (Categories 6 and 7) have had neither potential or catastrophic barrier failures

# Contamination Probability Hypothesis – Did it work?



Probability of hydrocarbon migration

$$P=0.05 \uparrow 3$$

$$P_{act}=0.024 \uparrow 3$$

1 per 8,000 wells – original hypothesis

10 per 17,950 wells ( 1 per 1,795)

– actual (4 times larger) – Why??

9 per 833 *poorly* constructed wells

1 per 15,995 *well* constructed wells

# Summary

1. Aquifers can be protected against “fracking”.
2. Migration of natural gas in wellbores occurs, but infrequently.
3. The probability of potential and catastrophic failure of one or more barriers increases with poor well construction methods.
4. *Most* of the failures occur on wells with *shallow surface casing* set above the base of the aquifer.
5. Horizontal wells for shale development benefit from the historical improvement in well construction methods.

# Acknowledgments



- This research is supported in part by the AirWaterGas Sustainability Research Network funded by the National Science Foundation under Grant No. CBET-1240584. Any opinion, findings, and conclusions or recommendations expressed in this presentation are those of the author and does not necessarily reflect the views of the United States National Science Foundation.



# Your Feedback is Important

**Enter your section in the DL Evaluation Contest by  
completing the evaluation form for this presentation  
Visit [SPE.org/dl](http://SPE.org/dl)**



Society of Petroleum Engineers  
Distinguished Lecturer Program  
[www.spe.org/dl](http://www.spe.org/dl)

